

.Add locite nr.243 on nr.34, nr.44 and nr.45
 .Lubricate with grease : nr.11 and nr.19
 .Lubricate with grease : nr.18 and nr.19
 .Use PP02203 KLEJ RED-SABA FOAMSPRAY 2203/2916 to glue nr.52
 .Tighten with torque wrench 25Nm W600135: nr.64 and Nr.27

Detail A

8001500

E000526 / Y

EAGLE 625				Plan No. / Plannr. E000526 / Y
Scale / Schaal: 1:10	Drafted / Getekend	Verified / Nagezien	Confirmed / Bevestigd	
Date / Datum	26/03/2010	14/07/2022	14/07/2022	
Init. / Init.	TM	SD	PJ	


Material			
No.	Plan	Article	Quantity
1	X001016	1001682	4
2	X001029	1375500	4
3	X004122	1692500	1
4	X004123	1692600	1
5	X004124	1692700	1
6	X004260	1708600	2
7	X004288	1903587	1
8	X004338	1708700	1
9	X004341	1708800	2
10	X004353	1903588	1
11	X004699	1905496	1
12	X004409	1711600	2
13	∅12x70	1905630	1
14	Y014084	16897..	1
15	Y014090	16898..	1
16	Y014091	16899..	1
18	P00032386	20824..	1
19	Y016461	17349..	1
20	Y014110	16902..	1
21	Y014399	17066..	1
22	X004720	1905571	1
23	∅25x12.2x0.7	1993500	2
24	∅4x14	1001584	4
25	M8 DIN934	1001671	4
26	M10 DIN985	1001683	4
27	M12 DIN985	1001684	1
28	M8	1006835	4
30	M5x20 ISO7380	1998368	2
31	M10x23	1903086	1
32	M10x80 DIN7991	1905617	2
33	X001398	1009689	1
34	M10x16	1903370	2
35	M12	1003294	1
36	DIN471 17.5-1.2	1904807	1

Material			
No.	Plan	Article	Quantity
37	---	1903402	2
38	---	1903403	2
39	M10x70 DIN7991/8.8	1903406	2
40	---	1918030	1
41	---	1918031	1
42	10 kN	1918028	1
43	---	1903578	1
44	M10x25 DIN7991	1903589	4
45	M8x16	1991858	2
46	M8x35	1993236	2
47	M8x40	1008739	2
48	∅10x50	1998885	1
49	∅25 M10x1	1999935	1
50	---	1918029	1
51	---	1918032	1
52	X004580	1904798	3
53	---	T001052	2
54	---	1904568	2
55	X004612	1904946	1
56	X004632	1905205	1
58	Y016681	F006290	1
60	X004738	1905658	1
61	---	1900641	2
62	∅5x18	1001589	1
64	M12 DIN934	1001673	1
67*	---	1918034	1
68	---	1906233	1

* Optional charger, not depicted

8001500

E000526 / Y

EAGLE 625				Plan No. / Plannr.
				E000526 / Y
Scale / Schaal: 1:10	Drafted / Getekend	Verified / Nagezien	Confirmed / Bevestigd	
Date / Datum	26/03/2010	14/07/2022	14/07/2022	
Init. / Init.	TM	SD	PJ	